

WINDOWS DOCUMENT — MEDIA SERVICE

CPU alert:

Login to server and check in task manager (To check the alert is real or false)




> Type "Get-process" in windows power shell and check which process is using more CPU,




Memory alert:

Login to server and check in task manager (To check the alert is real or false)



> Type "Task list" in command prompt for memory usage



Reboot alert:

➤ Check in, Event viewer > windows logs > system > check filter with event id "1074 or user 32"










critical Alert for FW critical Alert for RE critical Alert for RE critical Alert for ms_mediaserviceinfr ms_mediaserviceinfr ms_mediaserviceinfr



To check drive space:

> Open "drivespace.exe" in server and check which drive is using more space



Ping alert:

> Open command prompt and type "ping server ip address"

```
C:\Users\SivaMuru\ping 10.20.8.62

Pinging 10.20.8.62 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 10.20.8.62:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),


C:\Users\SivaMuru\ping 10.2.18.24

Pinging 10.2.18.24 with 32 bytes of data:
Reply from 10.2.18.24: bytes=32 time=138ms TTL=126

Ping statistics for 10.2.18.24:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 138ms, Maximum = 139ms, Average = 138ms

C:\Users\SivaMuru\>
```

> Check the uptime of server in network connections by typing "Ncpa.cpl" in run




Robot alert:

➤ Log into the server and open "Nimsoft service controller" and check the status of robot status



Service stopped alert:

Log into server, type "services.msc" in run and check the service status.



Disk Usage









critical Alert for FW critical Alert for RE critical Alert for clear Alert for ms_mediaserviceinfr ms_mediaserviceinfr ms_mediaserviceinfr